Typical Delivery Truck Installation Overview when using Samsung Galaxy Tab E



Printer (typically supplied by customer)

Generally mounted next to PC on mounting plate

Mount firefly with the power light is visible and protect from accidental damage

Firefly Serial BlueTooth Adapter

4-12 Volt DC power adapter needed when using meters other than the LCR

RAM Case & Sleeve

This connection between meter, printer and BT adaptervaries depending on MeterRegisterbut ususally consists of a LapPad adapter or cab mounted control box.

Lind Power Supply, can also be used to supply power to the Firely

Lind Power Supply, typically hard wired to truck power and provides power to Samsung and Firefly

RAM Mount

Lind Low Profile Shut Down

Mounting base supplied by customer

Legend

BlueTooth Connection

Meter Wiring

DC Power Wiring

DC Adapter to PC and Printer Wiring

12V DC
power from an always powered circuit

Vehicle Fuse Pane